



WA85GWG
WA85GWW

Washing Machine user manual



100%
Recycled Paper

This manual is made with 100% recycled paper.

imagine the possibilities

Thank you for purchasing this Samsung product. To receive more complete service, please register your product at www.samsung.com/register

SAMSUNG

features of your new washer

1. Magic detergent compartment

Since the water streams are emitted from four sides, the detergent is dissolved completely and there is no remaining detergent.

Since the detergent compartment is located at the top, you can easily add detergent and softener.

2. Diamond Drum

The diamond shaped drum creates a high water pressure, removing dirt from the laundry effectively. The diamond drum minimizes fabric damage extending the lifetime of the fabric. The glittering inner tube is both beautiful and powerful in the wash effect it creates.

3. Fuzzy Control

The Fuzzy control selects the optimal washing program by automatically sensing the washload using artificial intelligence.

4. Tempered Transparent Door

Tempered Transparent Door lets you observe while the washer is operating. Check on your laundry's progress at any time.

5. Magic Filter

The unique Magic Filter ensures that any lint inside the tub is captured for top quality filtering results that deliver a consistent and effective cleaning result.

6. Child-Lock Function

The Child-Lock function protects children from accidentally being hurt while playing with the washer.

This manual contains important information on the installation, use, and care of your new Samsung washer. Refer to it for descriptions of the control panel, instructions on how to use the washer, and tips for making the most of its state-of-the-art features and functions. The 'Troubleshooting and information codes' section on page 26 tells you what to do if something goes wrong with your new washer.

safety information

Throughout this manual, you'll see Warning  and Caution  notes. These warnings, cautions, and important safety instructions that follow do not cover all possible conditions and situations that may occur. It's your responsibility to use common sense, caution, and care when installing, maintaining, and operating your washer. Samsung is not liable for damages resulting from improper use.

IMPORTANT SAFETY SYMBOLS AND PRECAUTIONS

What the icons and signs in this user manual mean:

 WARNING	Hazards or unsafe practices that may result in severe personal injury or death .
 CAUTION	Hazards or unsafe practices that may result in minor personal injury or property damage .
 CAUTION	To reduce the risk of fire, explosion, electric shock, or personal injury when using your washer, follow these basic safety precautions:
	Do NOT attempt.
	Do NOT disassemble.
	Do NOT touch.
	Follow directions explicitly.
	Unplug the power plug from the wall socket.
	Make sure the machine is grounded to prevent electric shock.
	Call the service center for help.
	Notice

These warning signs are here to prevent injury to you and others.

Please follow them explicitly.

After reading this section, keep it in a safe place for future reference.

-  Read all instructions before using the appliance.

As with any equipment using electricity and moving parts, potential hazards exist. To safely operate this appliance, become familiar with its operation and exercise care when using it.

Install and store your washer inside, away from exposure to weather.

Install and level your washer on a floor that can support its weight.

-  Your washer must be properly grounded. Never plug it into an ungrounded outlet. See page 16 for more information on grounding your washer.

Position the washer so that a wall plug is accessible after the installation is completed.

safety information



To reduce the risk of fire or explosion:

- Do not wash items that have been washed, soaked, or treated with gasoline, dry cleaning solvents, or other flammable or explosive substances. They give off vapors that could ignite or explode. Rinse by hand any material that has been exposed to cleaning solvents or other flammable liquids or solids before putting it in your washer. Be sure that all traces of such liquids, solids, and fumes have been removed. Dangerous substances include acetone, denatured alcohol, gasoline, kerosene, certain liquid household cleaners and spot removers, turpentine, waxes, and wax removers.
- Do not put gasoline, dry cleaning solvents, or other flammable or explosive substances into the washer.
- Under certain conditions, hydrogen gas may be produced in a hot water system – such as your hot water heater - that has not been used for two weeks or more. **HYDROGEN GAS IS EXPLOSIVE.** If your hot water system has not been used for two weeks or more, turn on all hot water faucets in your home, and let the water flow for several minutes before using your washer. This will release any hydrogen gas build-up. Since hydrogen gas is flammable, do not smoke or light an open flame during this time.

Ventilate immediately without touching the power plug if there is a gas leak.



Unplug the power cord before servicing your washer.



Do not reach into the appliance when the tub is moving.



Do not reach under the appliance with your hands or with an object as you may be injured by the spinning board beneath the washer.



Do not let children play on or in your washer. The washer door does not open easily from the inside, and children may be seriously injured if trapped inside.



Do not let children attempt to look into the washer as falling into the washer is extremely dangerous and may be fatal.



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.



Do not repair, replace, or service any part of your washer yourself unless you fully understand the recommended user-repair instructions and have the skills to carry them out. Work done by an unauthorized person may void your warranty.

Store laundry detergents and other laundry supplies in a cool, dry place out of children's reach.

Disconnect the hoses and turn off the water when not using the washer.

If the power cord is damaged, it must be replaced by the manufacturer, a service agent or a similarly qualified person in order to avoid hazard.

Do not forcefully bend the power cable or place any Blanket objects on the cable.

Do not touch the power cord with wet hands.

Do not overload the power outlet with too many appliances.



If this appliance is supplied from a cord extension set or electrical portable outlet device, the cord extension set or electrical portable outlet device must be positioned so that it is not subject to splashing or ingress of moisture.

Do not install the washer nearby electrical implements and do not place any candles or cigarettes on the washer.

Do not go near the washer if it is flooded or under water, as there is a risk of electric shock. Unplug the washer and drain the water completely.



Do not combine chlorine bleach, ammonia, or acids (such as vinegar or rust remover) in the same wash. The fumes that can form when any of these items are combined are hazardous.

Do not machine wash fiberglass materials. Small particles can stick to fabrics washed in subsequent loads and cause skin irritation.

If this appliance is supplied from a cord extension set or electrical portable outlet device, the cord extension set or electrical portable outlet device must be positioned so that it is not subject to splashing or ingress of moisture.



Before disposing of your washer, remove the lid so that children or small animals cannot get trapped inside.

Connect the washer to the main water supply using a new set of hoses. Do not reuse an old set of hoses.

Water inlet hoses deteriorate over time. Check the hoses periodically for bulges, kinks, cuts, wear, and leaks, and replace them as needed and at least every five years.

Before each wash, empty the pockets of your laundry. Small, irregularly shaped hard objects, such as coins, knives, pins, and paperclips could damage your washer. Do not wash clothing with large buckles, buttons, or other heavy metal objects.

If the washer does not stop within 15 seconds after you open the lid, call a service agent immediately.

Connect the grounding wire to the shell plate, and bury it under at least 10 in (25 cm) of earth: Alternatively, connect the ground wire to the appropriate pin on a properly grounded power receptacle. Never connect the wire to a telephone line, lightning rod, or gas pipe.

For washers with ventilation openings in the base, that a carpet must not obstruct the openings.



The product you have purchased is designed for domestic use only.

The use for business purposes qualifies as product misuse. In this case, the product will not be covered by the standard warranty provided by Samsung and no responsibility can be attributed to Samsung for malfunctions or damages resulting from such misuse.

contents

SETTING UP YOUR WASHER

7

- 7 Checking the parts and the control panel
- 8 Control panel
 - 10 Fuzzy program
 - 10 Quick program
 - 10 Heavy Soil Course
 - 11 Blanket program
 - 11 Delicate program
 - 11 Wool program
 - 12 Water Saving program
 - 12 Tub Clean program
 - 12 Delay Start Course
 - 13 Last setting Course
 - 13 Child Lock
- 14 Manual functions (Selected models)
- 15 Meeting installation requirements
 - 15 Electrical supply and grounding
 - 15 Water supply
 - 15 Flooring
- 16 Installing your washer
- 19 Assembling the rat protection panel(option)

WASHING A LOAD OF LAUNDRY

20

- 20 Basic instructions
- 20 Laundry guidelines
- 22 Detergent and additives information
- 23 Washing for the first time
- 23 Automatic sensing function

CLEANING AND MAINTAINING YOUR WASHER

24

- 24 Keeping the tub clean
- 24 Cleaning the water supply connector filter
- 25 Cleaning the filter net

TROUBLESHOOTING AND INFORMATION CODES

26

- 26 Check these points if your washer...
- 28 Information codes

SPECIFICATION

29


- 29 Specification

setting up your washer

Be sure to have your installer follow these instructions closely so that your new washer works properly and so that you're not at risk of injury when doing laundry.

CHECKING THE PARTS AND THE CONTROL PANEL

Carefully unpack your washer, and make sure you've received all the parts shown below. If your washer was damaged during shipping, or if you do not have all the parts, contact Samsung Customer Service or your Samsung dealer.



Water supply hose



Drain hose



Manual book




Hose guide

setting up your washer

CONTROL PANEL

For more details, see control panel of your washing machine.



1 POWER BUTTON	Press this button once to turn the power on. Press it again to turn the power off.
2 START/PAUSE BUTTON	Press to pause and restart programs. To change the washing procedure during an operation, press this button to stop the operation, and press it again to restart the washer after changing the washing procedure.
3 PROGRAM BUTTON	Press this button repeatedly to cycle through the washing programs: Fuzzy → Quick → Heavy soil → Blanket → Delicate → Wool → Water Saving → Tub Clean
4 WASH BUTTON	Press this button to only perform a wash cycle or to adjust the wash time.
5 SPIN BUTTON	Press this button to only perform a spin cycle or to adjust the spin time. When only a spin cycle is selected, the spin time will be different from the total remaining time. This is because the total remaining time includes the actual spin time, the time for the water to drain and the washer to stop.
6 CHILD-LOCK FUNCTION	This is a device to protect children from being accidentally hurt while playing with the washer. - How to start the Child-Lock function: - Press the "Power" button to go to an initial washing mode. - By pressing "Start/Pause" button, you start washing and in case Child Lock function is needed during the laundry - Press both the "Rinse" and "Spin" buttons at the same time.(for 3 seconds) (Note: You cannot perform the function without the "Power" button on.) - To release the function of Child-Lock: In case the "Child-Lock" is programmed, press both the "Rinse" and "Spin" buttons at the same time.
7 RINSE BUTTON	Press this button to perform only the rinse cycle or to adjust the amount of rinse cycles.

8	REMAINING TIME, DELAY START TIME, ERROR DISPLAY	The display shows the remaining wash time, the reserved delayed start time or error messages.
9	SOAK BUTTON	Press this button to perform a soak wash. You can set the soak time from between 10 to 60 minutes. This function cannot be selected during a Wool and Clean tub program.
10	LAST SETTING BUTTON	Last setting button. Selects this course to load the settings for the last course. Perform a wash course using the last used settings without having to enter them manually again. Your choices are automatically saved when you press the Start/ Pause button. To use a memorized course, press the Last Settings button and then press the Start/Pause button.
11	DELAY START BUTTON	Press this button to finish the wash at a specified time. Turn your washer off to cancel a previously delayed start time. You can set the delayed start time from between 3 to 19 hours.
12	SOIL LEVEL BUTTON	You can select the water stream type. Heavy → Normal → Light → Off → Heavy You can change the setting depending on the course. You cannot change the setting during a spin cycle.
13	WATER LEVEL BUTTON	The water level is automatically adjusted. However, you can select the water level manually by repeatedly pressing this button.
14	WATER SUPPLY BUTTON	Press this button repeatedly to cycle through the water options: Cold → Cold & Hot → Hot → Cold

setting up your washer

Fuzzy program

Use this program to automatically select the optimal washing program.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Start/Pause** button. The water level is selected automatically.
The wash, rinse, and spin cycles will follow.
To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.
4. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.
5. Press the **Start/Pause** button.

Quick program

The Quick program is good for light or slightly stained laundry.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button turning the washer "On".
3. Press the **Program** select button.
4. Press the **Start/Pause** button. The water level is selected automatically.
The wash, rinse, and spin cycles will follow.
To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.
5. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.
6. Press the **Start/Pause** button.

Heavy Soil Course



Use this course, which adds the Soak cycle before the Wash cycle, to wash clothing stained with heavy dirt.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Program** select button. The water level is selected automatically.
4. Press the **Start/Pause** button.
The wash, rinse, and spin cycles follow.
To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.
5. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.
6. Press the **Start/Pause** button.

Blanket program

Use this program for big volume laundry items such as blankets and bed cover sheets.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Program** select button.
4. Press the **Start/Pasue** button.
The wash, rinse, and spin cycles will follow.
To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.
5. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.
 - Do not wash electric blankets and carpets.
 - Fold big volume laundry items (blankets and bed cover sheets) in the following way before adding them into the spin basket.
 - Purchase a laundry net for light and big volume laundry items (e.g. cashmere, blankets) as they may rise to the top of the washer and become damaged.
6. Press the **Start/Pause** button.



Delicate program

Washable sweater, cardigan, delicate clothes etc.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Program** select button.
4. Press the **Start/Pause** button.
The wash, rinse, and spin cycles will follow. If you want to pause, press the Start/Pause button again. You can change the course when paused.
5. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.
 - You cannot select the 'Hot' option for the water supply for this program.
 - The last spin operates lightly to prevent wrinkles.
 - Use the detergent indicated in the laundry.
6. Press the **Start/Pause** button.

Wool program

Use this program to wash woolen items such as washable sweaters, cardigans, and other woolen items.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Program** select button.
4. Press the **Start/Pause** button.
The wash, rinse, and spin cycles will follow.
To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.
5. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.
 - Only cold water can be selected to protect the laundry.
 - Refer to the Care Label on the clothing for the appropriate wash information.
 - Make sure buttons are fastened and that clothing is turned inside out.
 - Use only detergent indicated by the laundry.
6. Press the **Start/Pause** button.



setting up your washer

Water Saving program

This is a specifically designed course that enables you to wash laundry effectively with low amounts of water. Water Saving, Cold&Hot, Water Level 7 is recommended for a normally soiled cotton load."

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Program** button to select the Water Saving course.
4. Press the **Water Level** button to display level "7".
5. Press the **Water Supply** button to display "Cold" & "Hot".
6. Press the **Start/Pause** button.
 - To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.
7. Add detergent and fabric softener to the **Magic Detergent Compartment** according to the water level and close the cover.
8. Press the **Start/Pause** button.

Tub Clean program

Use this program to clean the tub. It will keep the tub clean and sanitary.

1. Close the door.
2. Press the **Power** button turning the washer "On".
3. Press the **Program** select button.
4. Press the **Start/Pause** button.

To pause a program, press the **Start/Pause** button again. You can change the program when it is paused.

 - Never place laundry in the tub when cleaning inside the tub, as this can cause discoloration or damage to the laundry.
 - When doing the laundry after cleaning the tub, you may find some impurities. These are just detergent residues and impurities after the tub cleaning. Perform the rinse cycle two to three times.
 - The initial water level is selected at the display water level "6".
 - You cannot select the 'Hot' option for the water supply for this program.
5. Press the **Start/Pause** button.

Delay Start Course

Use this to specify a time for the wash cycle to start, for example, when you need to go out and are unable to monitor the washer.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Program** select button.
4. Press the **Delay Start** button.

You may set the delay end time using the **Delay Start** button from between 3 to 19 hours.
5. Press the **Start/Pause** button.
6. Add detergent and softener to the **Magic detergent compartment** according to the water level and close the door.

The wash will finish by the set time.

 -  Detergent must be added into the detergent drawer.
 - If detergent is added onto the laundry directly, some clothes may become discolored because the start has been delayed.
 - To cancel a **Delay Start**, press the **Power** button.
7. Press the **Start/Pause** button.

Last setting Course

Using this function, you can select the most recently used courses. Whenever you press the Last Setting button, up to 3 recently used courses are displayed sequentially with the most recently used course displayed first. If you press the Last Setting button four times, the Fuzzy course is displayed.

1. Add the laundry into the tub and close the door.
2. Press the **Power** button to turn the washer "On".
3. Press the **Last Setting** button until the required course is displayed.
 - The recently used courses are displayed when you press the button (up to three times). If you press the button the fourth time, the Fuzzy course is selected. The corresponding course indicator blinks whenever you press the Last Setting button so that you can confirm the selected course.
4. Press the **Start/Pause** button.
 - The washer rotates the washing plate without supplying water, detects the weight of the laundry and shows the recommended water level.
5. Add the detergent and fabric softener to the **Magic Detergent Compartment** according to the water level and close the cover.
6. Press the **Start/Pause** button.

Child Lock

This function is for protecting children, the elderly and the frail.

1. Press the **Power** button.
2. To activate the Child Lock function, press and hold both the **Rinse** and **Spin** buttons down simultaneously for 3 seconds. (If the Child Lock function is activated, the Child Lock icon blinks.)
3. Operations after activating the Child Lock function.
 - Even if the Child Lock function is activated, every button works until the door opens.
 - When you open the door during the Child Lock is being activated, the alarm sounds and an error message appears. In 30 seconds, draining begins automatically. However, if you close the door within 30 seconds, water will not be drained. (Displayed error message "CL", "dE".)
 - To add laundry after activating the Child Lock function, you must deactivate the Child Lock function.
4. To deactivate the Child Lock function, press and hold both the **Rinse** and **Spin** buttons simultaneously for 3 seconds again. (If the Child Lock function is deactivated, the Child Lock icon is turned off.)
5. To clear "CL" display, after draining is complete, close the door of the washing turn the power off and then on.



- This function is for preventing injury and malfunction of the product because of inappropriate operations or actions by children, the elderly or the frail.
- If the door opens when the Child Lock function is activated, the water is drained by force to prevent children from drowning.
- To add laundry after activating the Child Lock function, you must deactivate the Child Lock.
- Even if the power is turned off and then on when the Click Lock is activated, the Child Lock remains activated.



- Once Child Lock is activated, even when the power is turned off, if the door is opened, water is automatically drained in 30 seconds.
- The Child Lock function cannot be deactivated when CL is displayed. (However, the Child Lock function can be deactivated when the dE error is displayed.)

setting up your washer

MANUAL FUNCTIONS (Selected models)

It is possible to select cycles manually.

(Example) A basic wash for lightly soiled laundry:

Power → Select the Quick program → Wash → Start/Pause

Program	INSTRUCTIONS
WASH ONLY 	Press the Power button. Press the Wash button. Press the Start/Pause button. The wash cycle continues for 18 minutes. When the Wash button is pressed while washing is in progress, the wash time can be changed to between 6 and 30 minutes.
RINSE ONLY 	Press the Power button. Press the Rinse button. Press the Start/Pause button. The rinse cycle is performed twice. When the Rinse button is pressed during the rinse cycle, the rinse time can be changed to between 1 to 5 times in duration.
SPIN ONLY 	Press the Power button. Press the Spin button. Press the Start/Pause button. When only the Spin cycle is selected, the remaining displayed spin time differs from the total remaining time. The total remaining time includes the time for draining and stopping the operation. Therefore, even if the two time values differ, this is not a problem. When the Spin button is pressed during the spin program, the spin time can be changed to 1 to 9 minutes.
WASH AND RINSE 	Press the Power button. Press the Wash and Rinse buttons. Press the Start/Pause button once. The cycle detects the amount of laundry, and automatically determines the wash and rinse times. When the Wash and Rinse buttons are pressed while the washer is in progress, the wash time is determined between 6 and 30 minutes, and the rinse time is determined between 1 and 5 times.
RINSE AND SPIN 	Press the Power button. Press the Rinse and Spin buttons. Press the Start/Pause button once. The washer rotates the washing plate without supplying water, detects the weight of the laundry and shows the recommended water level. The rinse and spin cycles are performed. When the Rinse and Spin buttons are pressed while the washer is operating, the number of rinse cycles is determined between 1 and 5 times, and the spin time is determined between 1 and 9 minutes.
WASH, RINSE AND SPIN 	Press the Power button. Press the Wash, Rinse and Spin buttons. Press the Start/Pause button once. The wash, rinse and spin cycles are performed.

MEETING INSTALLATION REQUIREMENTS

Electrical supply and grounding

To prevent unnecessary risk of fire, electrical shock, or personal injury, all wiring and grounding must be done in accordance with the National Electrical Code ANSI/FNPA, No. 70 Latest Revision and local codes and ordinances. It is the personal responsibility of the appliance owner to provide adequate electrical service for this appliance.

Never use an extension cord.

Use only the power cord that comes with your washer.

When preparing for the installation, ensure that your power supply offers:

- A fuse or circuit breaker
- An Individual branch circuit serving only your washer

Your washer must be grounded. If your washer malfunctions or breaks down, grounding will reduce the risk of electric shock by providing a path of least resistance for the electric current.

Your washer comes with a power cord having a three-prong grounding plug for use in a properly installed and grounded outlet.

Never connect the ground wire to plastic plumbing lines, gas lines, or hot water pipes.

Improperly connecting the equipment-grounding conductor can result in electrical shock. Check with a qualified electrician or service person if you question whether the washer is properly grounded. Do not modify the plug provided with the washer. If it does not fit the outlet, have a proper outlet installed by a qualified electrician.

Water supply

Your washer will fill properly when your water pressure is 0.05 MPa~0.78 Mpa (0.5~8.0 kg-f/cm²).

Water pressure less than 0.05 MPa (0.5 kg-f/cm²) may cause a water valve failure, not allowing the water valve to shut off completely. Or it may take the washer longer to fill than what the controls allow, resulting in your washer turning off. (A fill-time limit, designed to prevent overflows/flooding if an internal hose becomes loose, is built into the controls.)

The water faucets must be within 4 feet (122 cm) of the back of your washer for the provided inlet hoses provided to reach your washer.

You can reduce the risk of leaks and water damage by:

- Making water faucets easily accessible.
- Turning off faucets when the washer is not in use.
- Periodically checking for leaks at the water inlet hose fittings.

Before using your washer for the first time, check all connections at the water valve and faucets for leaks.

Flooring

For best performance, your washer must be installed on a solidly constructed floor.

Never install your washer on a platform or poorly supported structure.

setting up your washer

INSTALLING YOUR WASHER

Step 1

Selecting a location


Before you install your washer, make sure the location:

- Has a hard, level surface without carpeting or flooring that may obstruct ventilation and avoid vibrations
- Allows at least 4 in (10 cm) between the washer and the wall
- Is away from direct sunlight and not exposed to rain as moisture may destroy the electrical insulation causing an electrical shock hazard
- Has adequate ventilation
- Is not exposed to temperatures below freezing (below 32 °F and 0 °C)
- Is away from heat sources such as oil and gas
- Has enough space so that your washer doesn't stand on its power cable


Step 2

Connecting the water supply hose to the washer


Connect the other end of the water supply hose to the inlet water valve at the back of the washer. Screw the hose clockwise all the way in.




1. Remove the adaptor from the water supply hose.




2. First, using a "+" type screw driver, loosen the four screws on the adaptor. Next, take the adaptor and turn part(b) following the arrow for gap about 5 mm between them.



3. Connect adaptor to the water tap by tightening the screws firmly. Then, turn part(b) following the arrow and put (a) and (b) together.




4. Connect the water supply hose to the adaptor. Pull down the part (c) of the water supply hose. When the part (c) is released, the hose is automatically connected to the adaptor making a 'click' sound.



If water leaks from the hose after completing the connection, repeat the same steps again. Use the most conventional type of faucet for the water supply. If the faucet is square or too big, remove the spacing ring before inserting the faucet into the adaptor.


5. Connect the other end of the water supply hose to the inlet water valve at the back of the washer. Screw the hose clockwise all the way in.



- 5-1. Connect the other end of the water supply hose to the inlet water valve at the top of the washer. Screw the hose clockwise all the way in.



- If the water tap is a screw type, assemble a water supply hose that fits to the tap as shown. After completing connection, if water leaks from the hose, then repeat the same steps.




setting up your washer


Step 3

Connecting the drain hose


1. Remove the cap-hose and connect the outlet-hose.



2. Ensure that the drain hose is connected tightly to the drainoutlet on the side of the washer.



3. Install the drain hose about 35~39 in (90~100 cm) above the ground.



Powering and positioning your washer

1. Plug the power cord into a 3-pronged well-grounded fuse or comparable circuit breaker. (For more information on electrical and grounding requirements, see page 16.)
2. Slide the washer into position.

Adjusting the height of the washer

Make sure your washer is level by adjusting the leveling legs.



CAUTION Beware of catching your hands under the legs.


1. Pull the handles located at the right and left front of the washer and slide them off.
2. Adjust the height of the washer upwards or downwards.
3. When you have finished adjusting the height, push the handles back to fix the adjusting legs in place.




Waterdrop mark	Cause	How to level
	The front of the washer is lower	Level the washer by adjusting the legs.
	The back of the washer is lower	Adjust the height by using the props at the back.
	The left of the washer is lower	Adjust the left side by using the adjustable legs at the front and props at the back.
	The right of the washer is lower	Adjust the left side by using the adjustable legs at the front and props at the back.

ASSEMBLING THE RAT PROTECTION PANEL(OPTION)

1. Insert the rat protection panel to the assembling hole on front side to the end.



2. If you have difficulty inserting the panel lift up the washer a little and insert it.



washing a load of laundry

With your new washer, the hardest part of doing laundry will be deciding which load to do first.

BASIC INSTRUCTIONS

1. Load your laundry into the washer.
2. Close the door.
3. Turn the power on.
4. Add detergent and additives into the dispenser (see page 22).
Select the appropriate program and options for the load (see pages 11-15). The Wash Indicator light will illuminate and the estimated program time will appear in the display.
5. Press the **Start/Pause** button.

LAUNDRY GUIDELINES


Follow these simple guidelines for the cleanest laundry and the most efficient wash. (It is important that the checkpoints below are followed in order to avoid machine problems or clothing damage.)

If any problems arise due to the fault of the customer, a separate service fee will be charged to the customer.



Always check the Care label on clothing before washing.


- You can fill the tub with dry, unfolded clothes; but do NOT OVERLOAD the tub. Overloading may reduce washing efficiency, cause excess wear on your laundry and the washer, and possibly cause creasing or wrinkling of the load.
- When washing big, bulky items or a few smaller items that don't fill the tub completely - a rug, a pillow, stuffed toys, or one or two sweaters, for example - add a few towels to improve the tumbling and spinning performance.
- Check if any clothing items may bleach. Add liquid detergent to a white towel and the garment if you are unsure whether it may bleach. Rub the two items together strongly. Check if the color is transferred to the towel.
- Be especially careful with scarves and imported clothes since they discolor easily. Check for stains or partial dirt. If stains are found, add some detergent to a cloth and rub the stain in a single direction. Soil and dirt may rub against delicate garments causing damage and the wash result may be unsatisfactory.
- If clothes are too soiled, remove them and wash them separately, as dirt may transfer to the other clothing.
- Before washing the following items, sleeves, collars, dress hems and pockets should be pre-treated by brushing them with detergent. Wrinkle-processed clothing made of wool should be specially treated by tying them together (using thread) before washing. The thread is removed after the clothes have dried.
- Metal on clothing may damage your clothing as well as the tub. Turn clothing with buttons and embroidered clothes inside out before washing them. If pants and jacket zips are open during the wash, the spin basket may be damaged. Zips should be closed before washing.
- Clothing with long strings may become entangled with other clothes and damage them. Be sure to fix the strings before starting the wash.
- Turn delicate clothing inside out before washing it.



- Wash black clothing and cotton towels separately. If these are washed together, the towels may become stained. Check before washing.
- Curtains, light garments or blue jeans should not float. If they are floating, stop the washer by pressing the **Start/Pause** button and press them down until they are soaked in the water. If the wash continues with floating clothing, it may damage the laundry and the washer, as well as resulting in an unsatisfactory washing result.



Check all pockets before washing! Hairpins and coins may damage your clothing as well as your washer. It is important that you check pockets for objects and remove them.



Do NOT wash the following items

- Clothing that is easily disfigured even when simply soaking in water.
- Neckties, brassieres, jackets, suits and coats that are made mostly of rayon and other kind of blended fabrics can be easily disfigured (e.g. shrinkage and discoloration).
- Wrinkle-processed, embossed, or resin processed products that are easily disfigured even when simply soaking in water.
- Easily discolored products made of cotton and wool, wrinkled silk, leather products, leather accessory, leather ornamented clothes and its accessories.
- Do not wash waterproof clothing (e.g. ski wear, diaper covers and matts/rugs). This may cause the laundry to be ejected or cause the washer to vibrate abnormally, which may result in personal injury or damage to the washer, the floor or the clothing. When the tub rotates, water may become trapped in the waterproof clothing or fabric and can collect in a corner, causing abnormal vibrations. In addition, the laundry rises and may be ejected and cause personal injury.



Use a laundry net to wash the following items

- Use only commercial laundry nets.
- Place delicate clothes in a laundry net.
- Cashmilon and garments with a big volume and lightweight (e.g. lace decorated clothing, lingerie, nylon stockings, synthetic fabrics, etc.) may rise to the top of the washer and damage clothing and the washer. Use a laundry net or wash these items separately.
- Place long stringed and lace decorated clothing, bed cover sheets, and woolen clothes into a laundry net before washing them.




washing a load of laundry

DETERGENT AND ADDITIVES INFORMATION

Which detergent to use

Use powdered or liquid detergent. Do not use soap as the tub may become dirty from dirt on it.




Detergent compartment (a)



- Sprinkling powdered detergent directly onto the laundry causes clothes to discolor. Make sure to add detergent into the detergent compartment.
- When the water temperature or pressure is too low or only hot water is supplied, the detergent may not dissolve completely.
- Do not add foreign objects into the detergent compartment. The detergent compartment may be clogged.



- Adding detergent to the detergent compartment before the wash is recommended.
- Using the magic detergent compartment, you can effectively dissolve detergent and prevent any undissolved detergent in the laundry.
- For best results it is recommended to mix detergent with 1 litre of warm water before adding to the machine during the fill process.



To add softener (b)

1. Add the softener to just below the guide line (MAX).
2. After adding softener, make sure that you close the cover. Failing to do so may result in water splashing out of the compartment in areas with a high tap water pressure.
3. Softener is automatically added to the water for the last rinse cycle.


Please add softener to the compartment before running the washer.



- Add normal softener.
(If you add softener for a drum washer or sticky softener, the softener compartment may be contaminated or softener may remain in the compartment.)



- For highly-condensed softeners, the softener may not be added into the water in areas with low tap water pressure.
- In areas with low tap water pressure, add the softener directly to the wash tub as the softener may not be added into the tub automatically.



WASHING FOR THE FIRST TIME

Before starting to wash, check the following:

1. Connect the water supply hose to the water tap. Open the tap. Connect the power to the washer. Ensure that the drain hose is placed properly.
2. Make sure the drain hose is installed properly.

Before performing a wash for the first time, you must run a complete cycle without adding any laundry.

1. Press the **Power** button.
2. Open the detergent drawer and insert a little detergent.
3. Turn on the water supply to the washer.
4. Press the **Start/Pause** button.

This will remove any water remaining from the manufacturer's test run.

AUTOMATIC SENSING FUNCTION

Your washer is equipped with an automatic sensing function which automatically senses the amount of laundry and the appropriate water level, wash time, rinse cycle, and spin time.



This does not apply for the Soak and Wool programs.

Special notes!

After the power is on, a program is selected and the **Start/Pause** button is pressed, the washing board starts spinning without water. This action senses how much laundry is in the washing basket, and this is not a machine problem. After the sensing process has completed, water is supplied automatically.

cleaning and maintaining your washer


Keeping your washer clean improves its performance, wards off unnecessary repairs, and lengthens its life.

KEEPING THE TUB CLEAN


When using the machine under humid conditions for an extended time, various airborne bacteria may stick to the tub and form mold, causing harm to humans. Keep the tub clean and hygienic at all times.

CLEANING THE WATER SUPPLY CONNECTOR FILTER


1. Remove the filter and wash it well.




2. Return the filter to its place and securely connect the hose to the inlet water valve.



3. Check if there is any water leakage. Ensure that the connector is connected tightly.




4. When using cold water only, cover the hot water supply hose connector with the cap. Failing to do so may result in water leaking from the hot water supply hose connector.




CLEANING THE FILTER NET

Clean the filter net regularly to keep the washer clean.


1. Push and pull the upper part of the Magic filter downwards at the same time.



2. Open the cover as shown in the figure.



3. Clean the Magic filter.



4. Close the cover and first insert the lower part of the filter into the basket and then push the filter until you hear a "clicking" sound.



troubleshooting and information codes

CHECK THESE POINTS IF YOUR WASHER...

PROBLEM	CHECK & SOLUTION
Has no power.	Check if the electric voltage is normal.
	Check if the washer is plugged in. Make sure the electric cord is plugged in.
Dose Not Drain	Make sure that the drain hose is not twisted or folded.
	Make sure that the drain hose outlet is not clogged.
Does Not Work	Is the washer lid open? ☛ Close the lid.
	Is the Hold button on? ☛ Press the Start/Pause button again, and check if the washer starts.
	Has sufficient water filled up to the water level? ☛ If the water pressure is low, it takes along time for water to fill the washer.
	Is the faucet closed? ☛ Open the faucet to supply water.
Has the drain hose and spin basket frozen.	• Add hot water to the frozen water tap and remove the drain hose. Soak it in hot water. • Pour hot water into the spin basket for about 10 minutes. • Place a hot water towel on the drain hose connector. • When the drain hose has been defrosted, reconnect it and check if the water is draining properly.
The water leaks at the water supply hose connector.	If the faucet connecting part is loose, water may leak. ☛ Repeat the assembling steps again. (Refer to "Connecting the water supply hose")
	Check if the rubber ring of the water supply hose is in the right position. ☛ Fit it tightly again.
	Is the water supply hose folded? ☛ Unfold the hose.
	If the water supply is too strong, water may leak. ☛ Close the faucet a little.
	Is water leaking from the faucet itself? ☛ Fix the faucet. Water is not supplied.
	Did you press the Start/Pause button after selecting the water supply? ☛ The Start/Pause button must be pressed for water, for water to be supplied. Press the Start/Pause button.

PROBLEM	CHECK & SOLUTION
When no water is extracted	Make sure that the faucet is on. ➡ Turn on the faucet.
	Check if the filter net at the water supply hose connector is clogged with dirt. ➡ Clean the filter net using a toothbrush.
	Make sure the water supply is on. ➡ If the water supply is suspended, turn both the faucet and power on.
Spinning causes loud noises and vibrations.	Check if the laundry is spread out evenly in the washer. ➡ Spread out the laundry evenly and start again.
	Check if the washer is balanced and level on a sturdy flat floor surface. ➡ Ensure that the washer is level.
	Check if the leveling legs are loose. ➡ Adjust the leveling legs so that the washer is even.
	Ensure that the washer is not surrounded with unnecessary items. ➡ Remove anything unnecessary away from the washer.

troubleshooting and information codes

INFORMATION CODES

When your washer malfunctions, you may see an information code on the display. If that happens, please check this table and try the suggested solution before calling Customer Service.

CODE SYMBOL	CHECK
SE	This code is displayed with an alarm sound if the water is not drained after 30 minutes. - Check if the drain hose is clogged by a foreign object. - Press the Start/Pause button to resume the operation.
UE	This code is displayed if the spin operation fails. - Check if the laundry is pushed to one side. - Check if the washer is installed evenly.
LE	This code is displayed with an alarm sound if the water level is not changed after 4 minutes. This code is also displayed with an alarm sound if the water supply is not completed after 60 minutes. - Check if the tap water faucet has been opened, if tap water is supplied, and if the tap water pipe is frozen. - Check if the amount of supplied tap water is too little. - Check if the filter of the drain hose connecting hole is clogged by a foreign object. - Press the Start/Pause button to resume the operation.
OE	This code is displayed when the cover is opened. - Check if the cover is opened. - To resume the operation, open and close the cover. - If you close the cover when the Child-Lock function is active, 'CL' is displayed. To resume the operation, turn the power off and then on again.
CL	This code is displayed when the Child-Lock function is active. - The Child-Lock function prevents children from falling into the wash tub and drowning. - If 30 seconds have passed after opening the cover when the Child-Lock function is active, 'CL' is displayed and the washer does not run. (If there was water in the washing tub, the water is automatically drained.) - To resume the operation, close the cover and turn the power off and then on again. - To cancel the Child-Lock function when 'CL' is not displayed, press and hold both the Rinse and Spin buttons at the same time for at least 3 seconds.
BE PE SE SE2 SE OE OE2 PE LE LE (Other information codes)	The product may be out of order. In this case, please contact your nearest Samsung Electronics dealer or service center.

specification

SPECIFICATION

MODEL	WA85GWWG, WA85GWW
MAX. MASS OF DRY CLOTH IN kg	8.5 kg
WASHING TYPE	Stirring Type
POWER CONSUMPTION	600 W
DIMENSIONS (mm)	W630 X D675 X H1030
WEIGHT	48 kg
STANDARD WATER LEVEL	90 ℓ
WATER PRESSURE	0.05MPa ~ 0.78 Mpa (0.5 ~ 8.0 kg-f/cm ²)
WATER USAGE	260 ℓ
SPIN SPEED	700 rpm

memo

memo



QUESTIONS OR COMMENTS?

Country	CALL	OR VISIT US ONLINE AT
AUSTRALIA	1300 362 603	www.samsung.com

Code No. DC68-03222A-02_EN